



PREMIUM WIRELESS KEYBOARD WITH INTEGRATED TRACKBALL



Install the three (3) included AA batteries into the slot on the bottom of the keyboard.

WARNING:

You must install the batteries with the positive and negative terminals in the correct position to avoid permanently damaging the keyboard. Instructions are inside the battery compartment.

INSTALLATION / SYNCHRONIZATION INSTRUCTIONS:

1. Connect the USB receiver to the USB extension cable, and **place the USB receiver in a location where it will have full line-of-sight with your keyboard at all times.**
2. Bring the wireless keyboard within 3 feet of the USB receiver with clear line-of-sight (i.e. no obstructions).
3. Look for a small **receiver synchronization button** on the USB receiver, as shown on the right. Be sure it is connected to a USB port on the VidaBox™.
4. Using a paper clip or other small object, press and hold the **receiver synchronization button** down for at least 2 seconds.
5. On the wireless keyboard, hit the **keyboard synchronization button**, as shown above. Give the keyboard a few moments, and it should connect to the USB receiver.
6. If this does not work, replace the batteries with a fresh set and try again. Also note that less expensive, non-brand name "economic" batteries are not recommended for use with our equipment, as they may not supply enough energy for performance. If the problem persists, please contact us.



If you have changed the batteries, you may need to resynchronize the keyboard with the receiver by pressing this button.