



## Installation Instructions

### Suction Cup Kit for VESA Surface Mounts Ideal for Glass Surfaces

This kit includes:

- (1) Alcohol Wipe
- (4) Suction Cups
- (4) Plastite Screws


1. Using the alcohol wipe, clean the glass surface where we will be mounting the wall plate. Be sure the surface is free of dirty, grime, or other debris to ensure a secure installation.

Note: Take the time & effort to properly clean the glass surface. Any contaminants will compromise the suction cup kit's strength. Additional cleaning may be required above and beyond using the supplied alcohol wipe to ensure the surface is truly clean.



2. Next, insert the (1) of the (4) Plastite screws into the VESA mount we are using. (An example is shown on the right with our "Tilting" VESA mount wall bracket.)

Install screw  
& line up  
suction cup  
here (1 of 4)



3. Line up the suction cup's center hole with the end of the Plastite screw.
4. Using a power tool, drill the Plastite screw into firmly into the suction cup.  
**MAKE SURE THAT THE SCREW DRILLS IN ALL THE WAY FIRMLY.**
5. Repeat steps 2 to 4 for all (4) holes of the VESA mount, so that there are a total of (4) suction cups installed.
6. The VESA mount is now ready for use, and be stuck directly onto any glass wall!  
Install the VESA mount as you see fit.  
The installation is now finished.